iClear User Guide

The iClear electronic cigarette is an ideal kit for both new and experienced users of electronic cigarettes who are looking for a high quality and easy to use rechargeable electronic cigarette.

The iClear uses transparent cartomizers, which hold 0.9ml of e-liquid allowing easy viewing of the remaining fluid level, combined with a unique induction charging system which allows the user to charge the electronic cigarette without taking it apart.

This unique kit is the newest in cartomizer and charging technology, providing you with an attractive e-cig at an affordable price.

Kit Contents:

- 1 x Rechargeable 180mAh Lithium Battery
- 2 x Empty Refillable Cartomizers
- 10ml TECC Titan Fluid
- 10ml Needle Filling Bottle
- 1 x USB Magnetic Charger
- 1 x User Manual

Assembly & Use – Screw a filled cartomizer onto the battery, finger tight. Gently inhale for 3-5 seconds and exhale when ready.

Charging – When the battery flashes rapidly or the vapour production reduces, whilst the cartomizer contains fluid, the battery requires charging.

Insert the charger into a USB port; a blue light will display.

Insert the iClear e-cig without disassembling the components, end down, into the hole at the end of the charger. You will it click as the magnet engages. The light on the charger will flash blue then turn to red to indicate a successful connection and blink/fill incrementally until complete. Once the light returns to blue, the battery is fully charged.

Charging normally takes around 90-150 minutes depending on the source of power.

If the contact between the battery and charger is not established, the charger will continually flash blue. Remove the battery and clean the contact before reinserting.

Cartomizer Refilling

- Remove the rubber cap either by hand or with a pin/paperclip.
- A blunt ended syringe or refilling needle is required – fill the cartomizer using via either of the two small holes on the outer edges of the cartomizer.

- Avoid getting any liquid into the narrow central cylinder within the cartomizer as this space allows for airflow (see final step if you suspect liquid has entered the central cylinder).
- Replace the cap.
- Blow through the cartomizer from the mouthpiece end to ensure no liquid remains in the central air-flow cylinder.

Troubleshooting and FAQ

My iClear produces no vapour – ensure full and proper connectivity between the battery and the cartomizer. Detach the same if necessary and clean all visible threading with dry tissue. Ensure the battery is fully charged (if blinking, initiate a recharge). Try one or more new cartomizers to confirm if the issue is with the battery or try another battery.

TIP – iClear cartomizers use a standard 510-Type connection – if in doubt, attempt to use the cartomizer on another battery with a matching connection to determine possible failure of the cartomizer. Cartomizers have a typical average lifespan of around one week.

My iClear is leaking - ensure you maintain long but slow draws. Harsh draws may cause liquid to become trapped in the air-flow chamber within the cartomizer which can end up being drawn back up the cartomizer into the mouth. Ensure when filling the cartomizer that no liquid is allowed to enter the central cylinder – to ensure this, prior to connecting the cartomizer to the battery, blow through it from the mouthpiece end onto tissue.

My batteries will not charge – check the charger when connected to the power source without a battery connected – in normal circumstances the LED should appear blue. If there is no light at all, attempt to use another USB port or connect directly to the mains with a wall adaptor. If the problem persists, the charger may require replacing.

If the charger illuminates as normal but upon connection of the battery remains the same blue colour – disconnect the battery and clean the magnetic end and blow into the charging unit and reconnect. Should the light continue to stay blue on the charger, the battery may be refusing to accept a charge which may indicate that it has reached the end of its natural cell life and would require replacing.

TIP – iClear batteries measure 180mAh in capacity and have a typical lifespan based on at least one charge daily of around 4-8 weeks. Batteries are covered for a 28-day period under warranty from the date of receipt. Chargers have a 12-month electrical warranty.

My iClear continues to activate after ceasing to inhale - if the device continues to activate (indicated by a continued blue light on the end of the battery after) without using it, this may suggest that liquid has entered the connecting threads of the battery affecting the workings of the air-flow sensor . Attempt to clean the battery threads with dry tissue. Avoid harsh inhalations to avoid leaking in the first instance and correctly follow the cartomizer refilling guide – should the problem appear irreparable and the battery is still under warranty, contact customer services.

Can I use any liquid in iClear Cartomizers – whilst we recommend using only our own branded e-liquids which have the ideal PG to VG consistency for most atomizers/cartomizers it is feasible to use any e-liquid, however those with a higher viscosity may cause premature failure of cartomizers.

TECC™
The Electronic Cigarette Company